


Item No.	Part No.	Description	Qty.	Item No.	Part No.	Description	Qty.	Item No.	Part No.	Description	Qty.	Item No.	Part No.	Description	Qty.
1	18371-C	Electrical Assembly	1	14	Stop Button	CH 10250T30R	1	27		3/4-10 Jam Nut	2	40	36013-B	Door Hinge Bracket	1
2	182T	3hp 230/460v. Motor	1	15		Push Button Box	1	28	HS-398-A	Spacer	1	41	18292-A	Lower Stabilizer Channel	1
3	18246-A	Grob Vari-Drive Pulley	1	16	18393-A	Blank Plate	1	29	18210-A	Speed Adjustment Nut	1	42	18293-A	Upper Stabilizer Channel	1
4	18122-A	Air Blower Support Plate	1	17	18128-A	Cover	1	30	18183-A	Spacer	1	43	36024-B	Lower Saw Band Guard	1
5	36044-A	Speed Indicator Pointer	1	18	24021-A	Speed Chart	1	31	S-1167-A	Washer	1	44	18291-A	Upper Table Support Brkt.	1
6	18111-B	Sawing Chart	1	19	18390	Speed Adj. Handwheel	1	32	FF-620-5	Oilite Bushing	1	45	18284-C	Table Assembly	1
7	GS-2077-A	Lower Wheel Brush Ass'y.	1	20	18121-B	Motor Support Plate	1	33		5/16" Flat Washer	1	46	36017-C	Head Assembly	1
8	18285-A	Switch Assembly	1	21	18218-A	Motor Clamp Plate	2	34		5/16-18 x 1/2 Hex Bolt	1	47	18180-C	Transmission Assembly	1
9	2322V681	4V-36 Vari-Speed Drive Belt	1	22	18117-B	Motor Slide Channel	1	35	24007-C	Lower Saw Pulley	1	48	36011-D	Frame	1
10	GS-2286-B	Blank Plate	1	23	F-319-A	Bushing	1	36	S-1361	Rubber Tire	1	49	24001-C	Drive Pulley	1
11	18321-A	Push Button Plate	1	24	36009-A	Screw Support	1	37	18295-A	Table Support Pin	2	50	24014-A	Rear Base Cover	1
12	18323-A	Gasket	1	25	36008-A	Screw Support Clamp	1	38	GS-2212-A	Door Knob Assembly	1	51	24013-B	Rear Base Support Channel	1
13	Start Button	CH 10250T30B	1	26	36007-A	Speed Adjustment Screw	1	39	36012-B	Base Door	1	52	18189-A	Leg Cover for 18174 Leg	4
												53	S-909-B	Table Extension	6



GROB INC.

GRAFTON, WIS.

Parts List Drawing for 4V-36 Band Saw

DRN. Grob8	TR. KS	CH.	DWG. NO.
DATE 9-17-02	SCALE 1:10	O.K. Rev 2	36015-C